



Connector to Harness Index

Front Passenger's Door Wire Harness (Coupe)

Ref	Connector or Terminal	Cavities/ Color	Location	Connects to	Notes
1	Passenger's under-dash fuse/relay box connector E (see page 6-4)	2-LT GRN	Behind right fuse box cover		Canada
2	Passenger's under-dash fuse/relay box connector F (see page 6-4)	20-LT GRN	Behind right fuse box cover		
3	Right power mirror	6-N/A	Front passenger's door		Canada
3	Right power mirror	3-GRY	Front passenger's door		USA
4	Front passenger's door lock switch	3-GRY	Front passenger's door		
5	Front passenger's window switch	6-GRY	Front passenger's door		
6	Front passenger's door key cylinder switch	3-GRY	Front passenger's door		
7	Front passenger's door lock knob switch	3-GRY	Front passenger's door		
8	Front passenger's door lock actuator	2-GRY	Front passenger's door		
9	Front passenger's door courtesy light	2-GRY	Front passenger's door		
10	Front passenger's window motor	2-GRY	Front passenger's door		
11	Front passenger's door speaker	2-GRY	Front passenger's door		

